

HARDIN MARINE

PART NUMBER: 137-9235 MODULAR END CAP

DESCRIPTION:
TRANSOM BRACKET DRILL TEMPLATE & INSTALLATION INSTRUCTIONS.

TRANSOM BRACKET INSTALLATION INSTRUCTIONS:

- 1.) CUT OUT APPROPRIATE TEMPLATE BELOW.
- 2.) TAPE TEMPLATE ON THE REQUIRED DIMENSION FROM THE GIMBAL HOUSING. ON THE SAME LEVEL PLANE WITH CRANKSHAFT CENTERLINE.
- 3.) CENTER PUNCH & DRILL (4) 13/32 HOLES.
- 4.) MOUNT CYLINDER ASSEMBLY TO TRANSOM WITH 3/8 NUTS, BOLT & WASHERS. PLACE THE BACKING PLATE ON THE INSIDE THE BOAT. TORQUE BOLTS TO 30-35 FT. LBS..

PORT SIDE

STARBOARD SIDE

