

Bolt Together Drive Stand 525-2000

TOOLS REQUIRED:
7/16" Wrench or Ratchet



1) Lay Base Plate flat on work surface. Caster flanges should be down.



2) Install first arm facing inwards.



3) Install second arm facing inwards.



4) Install bolts with the button head on inside.



5) Install all 6 bolts on the bottom.



6) Install arms long end facing bases long end.



7) Install bolts with the button head on inside.



8) Install all 6 bolts on the top.



8) Install the 4 casters and you are finished.